

Navigating the menus: For all functions involving the dash (EVIC) display, the EVIC screen first needs to be in a state where it's showing **AUDIO ON THE DASH SCREEN**.

TO START

IGNITION ON RUN – ENGINE NOT RUNNING

GO TO- "MARRY" FIRST IN SETTINGS -----

Marry/Unmarry: To advance to any of the vehicle settings, you will first need to "Marry" the Tazer to the vehicle. Simply select this option, and the Tazer will download your Jeep's current (stock) settings. This takes approx. 15 seconds, do not disturb this process. Once complete, you will be able to advance to the settings choices. Select "unmarry" to return the vehicle to stock. A couple cycles of the vehicle being started then allowed to sleep may be needed for all setting changes to take place. Any changes to the radio settings will require a "full reboot" to be selected.

**PRESS LEFT ARROW, THEN LET GO.
THEN UP/DOWN ARROW TO UNTIL YOU SEE "AUDIO" IN DASH
SCREEN.**

**THEN HOLD LEFT ARROW PLUS TAP THE CRUISE "CANCEL" FOR
SETTINGS MENU**

**KEEP PRESSING "CANCEL" AGAIN TO ADVANCE THROUGH
SETTINGS, SLOW**

- **LEFT ARROW PLUS CRUISE "ON/OFF" TO CHANGE OR SELECT
SETTING**
 - **LEFT ARROW PLUS CRUISE "RES" TO EXIT**
 - **SOME SETTINGS USE LEFT ARROW PLUS CRUISE +/- TO RAISE OR LOWER VALUES**
 - **LEFT ARROW ONLY TO REVERT BACK TO AUDIO DISPLAY**
-