

## REMOVAL AND INSTALLATION

### REMOVAL

1. Disconnect and isolate the negative battery cable(s) (Refer to 08 - Electrical/Battery System/Standard Procedure).
2. Remove the instrument panel pad (Refer to 23 - Body/Instrument Panel/PAD, Instrument Panel/Removal and Installation).
3. Remove the four screws (1) along the top of bezel.
4. Using a trim stick or equivalent, disengage bezel (2) from lower retaining clips and remove.



### INSTALLATION

1. Position the instrument cluster bezel (2) and hand tap to engage the retaining clips.
2. Install the screws (1) along top of bezel and tighten securely.



3. Install the instrument panel pad (Refer to 23 - Body/Instrument Panel/PAD, Instrument Panel/Removal and Installation).
4. Connect the negative battery cable(s) (Refer to 08 - Electrical/Battery System/Standard Procedure).