

For all configurations (Main, Aux or both)
Positive cable to Main battery Positive Terminal
Negative cable to ground

For all configurations (Main, Aux or both)
Positive cable to Main battery Positive Terminal
Negative cable to ground

Disconnect ground cable from IBS **(B)**

Disconnect ground cable from IBS **(B)**

Disconnect Aux battery ground (A)
and either
Install an N1 to N2 (Fused) Jumper (C1)
or
Unplug the PCR (C2)
(Requires a good PCR and good PCR Fuse)

Disconnect Aux battery ground (A)
and either
Install an N1 to N2 (Fused) Jumper (C1)
or
Unplug the PCR (C2)
(Requires a good PCR and good PCR Fuse)

